



The weighing station is a certified scale, designed and realised for the certified weighing of the parent rolls. It is equipped with a connected frame and counter-frame with compression loading cells opportunely positioned, to guarantee a precise and constant weighing. The roll support system in the weighing phase is of in plastic material so as to NOT ruin the surfaces of the cores. The weight is visualised on the display and/or transmitted to all automation systems present (including BONFANTI machines and/or warehouses).

The waiting stalls are used to uncouple the missions of loading/unloading the winder and slitter. Thanks to the waiting stalls, the interlocking times of the production lines may be drastically reduced. The waiting stalls guarantee a "contact free" placement as well.

